

# Soft Reads



**MIRION**  
TECHNOLOGIES

Dosimetry Services Division

# TABLE OF CONTENTS

## Contents

Overview .....	- 3 -
The Benefit .....	- 3 -
The Difference Between a Soft Read and Dose Reported .....	- 3 -
CONTACT .....	- 4 -

## Overview

The instadose wireless line of dosimeters provides you with the ability to narrow down when a high dose incident occurred.

Here's how! Each dosimeter takes a soft read once a day. Soft reads are scheduled to occur once a day automatically. A soft read looks at one chamber on the dosimeter and sends that data at the scheduled read date or when a manual read is performed.

Soft reads can be viewed by the account or location administrator through our online account management program AMP+. Simply click "Instadose+ Daily Dose Reads", select a dosimeter and enter the dates to view to view the data.

## The Benefit

If a wearer receives a high dose you can view the daily dose reads for the dosimeter to narrow down when the dose occurred. This helps you and your employees to know when a dose occurred, improving safety within your facility.

## The Difference Between a Soft Read and Dose Reported

As mentioned earlier a soft read is only reading the current state of one chamber on the dosimeter taking a snap shot in time. Reported doses are reporting on both chambers providing the true dose read. Therefore reported doses and soft reads may never equate to the same amount.

## CONTACT



**MIRION**  
TECHNOLOGIES

Dosimetry Services  
Division

2652 McGaw Ave, Irvine, CA 92614  
USA

U.S. / Canada: +800.251.3331

U.K. : 0170.629.9329

Worldwide: +1.949.419.1000

[instadoseplus@mirion.com](mailto:instadoseplus@mirion.com)